ENTER WITH CALL SIGNAL CUE VOICE 12 46 GENERATOR 44 CUE VOICE GENERATOR RESPONSE YES 6000 RECORD RESPONSE SECOND TRY YES 6000 J CUE VOICE PURGE GENERATOR RECORD EXIT CUE INTERNAL MEMORY 68. .70 FETCH CALL SEQUENCE #; ASSIGN DESIGNATION; ENCODE - SEQUENCE # CUE VOICE . GENERATOR 1.0. YES ACKNOWLEDGED CODE 01617 86 CUE VOICE GENERATOR 76 RECORD DATA YES SECOND TRY 6000 CUE VOICE GENERATOR PURGE 90 RECORD EXIT EXIT